

SRR Radio România Actualități

kHz	lan Mon = 1 ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
531	ro	HD Petroșani/Aninoasa	15		Harris/DX-15	45.375111,23.343056
558	ro	GJ Târgu Jiu	400	145°	Harris/DX-400	45.017778,23.292556
567	ro	BV Brașov/Bod Colonie	50		Harris/3DX-50	45.755261,25.607367
567	ro	SM Satu Mare	50	120°	Harris/3DX-50	47.854750,22.974222
603	ro	BT Botoșani	50	050°	Harris/3DX-50	47.725444,26.673461
603	ro	BH Oradea/Rontău	50	?		46.999403,22.005028
711	ro	MM Sighetu Marmației/Vadu Izei	50		Harris/3DX-50	47.877289,23.942892
720	ro	MM Baia Mare	10		Harris/DX-10	47.660339,23.596903
720	ro	TL Nufăru/Releul Delta	15		Harris/DX-15	45.150194,28.924583
720	ro	PH Sinaia	15		Harris/DX-15	45.374389,25.549833
756	ro	0800-2400 TM Lugoj/Boldur	400	190°	Harris/DX-400	45.688594,21.798350
855	ro	IF Tâncăbești (București)	400		Harris/DX-400	44.671111,26.080556
909	ro	TM Timișoara/Săcălaz	50		Harris/3DX-50	45.748528,21.077611
945	ro	HR Miercurea Ciuc	15		Harris/DX-15	46.367278,25.814500
1152	ro	0450-2400 CJ Cluj-Napoca/Jucu	400		Harris/DX-400	46.867139,23.807611
1179	ro	BC Bacău/Galbeni	400		Harris/DX-400	46.755722,26.847778
1179	ro	CS Reșița	10		Harris/DX-10	45.288378,21.867006
1332	ro	GL Galați/Barboși	50		Harris/3DX-50	45.403822,27.994522
1404	ro	SB Sibiu	15		Harris/DX-15	45.793272,24.138119
1422	ro	VL Râmnicu Vâlcea/Olănești	10		Harris/DX-10	45.104667,24.335333
1458	ro	CT Constanța/Valu lui Traian	100	?		44.169306,28.540178
1530	ro	SV Rădăuți/Mihăileni	15		Harris/DX-15	47.857336,25.913753
1593	ro	CT Ion Corvin	15		Harris/DX-15	44.116958,27.801311

SRR Antena Satelor

kHz	lan Mon = 1 ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
153	ro	BV Brașov/Bod Colonie	200		Harris/DX-200	45.755261,25.607367
531	ro	0550-2200 IL Urziceni	15		Harris/DX-15	44.709772,26.610850
630	ro	0550-2200 DB Voinești	50	135°	Harris/3DX-50	45.056833,25.261667
1314	ro	0550-2200 CT Constanța/Valu lui Traian	50	?		44.169306,28.540178

SRR Antena Satelor/Radio Bukarest/Bukaresti Rádió

kHz	lan Mon = 1 ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
603	xx	0550-2200 BU București/Herăstrău	30	175°	?	44.477033,26.051619
1314	xx	0550-2200 TM Timișoara/Săcălaz	25		Harris/3DX-25	45.748528,21.077611

regional program	lan Mon = 1 ROU time
	ro7 0550-1000
	ro 123456. 0550-1400
	hu7 1000-1020(2)
SRR Radio Bukarest(1)	de7 1020-1030(1)
SRR Bukaresti Rádió(2)	ro7 1030-2200
	de 123456. 1400-1500(1)
	hu 123456. 1500-1600(2)
	ro 123456. 1600-2200

SRR Radio Constanța

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
909	xx		0550-2200	CT Constanța/Valu lui Traian	25	?		44.169306,28.540178
1530	xx		0550-2200	TL Nufăru/Releul Delta	15		Harris/DX-15	45.150194,28.924583

regional program	lan	Mon = 1	ROU time
	ro	12345.7	0550-2100
	ro6.	0550-2200
	el	1.....	2100-2200
	tr	.2.....	2100-2200
	ru	..3....	2100-2200
	tt	...4...	2100-2200
	hy5..	2100-2200
	rup7	2100-2200

SRR Radio Iași

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
1053	ro		0555-2200	IS Iași/Lețcani	400		Harris/DX-400	47.181944,27.457222

SRR Radio Oltenia-Craiova

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
603	ro			MH Drobeta-Turnu Severin	15	065°	Harris/DX-15	44.645556,22.638656
1314	ro			DJ Craiova	15		Harris/DX-15	44.304761,23.780692

SRR Radio Timișoara

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
630	xx			TM Timișoara/Orțișoara	400	125°	Harris/DX-400	45.967222,21.215278

regional program	lan	Mon = 1	ROU time
	ro		0000-1300
	de		1300-1400(1)
	hu		1400-1500(2)
	sr		1500-1600(3)
SRR Radio Temeswar(1)	ro7	1600-1630
SRR Rádió Temesvár(2)	ro	123456.	1600-2400
SRR Radio Temišvar(3)	cs7	1630-1700(4)
SRR Rádió Temešvár(4)	sk7	1700-1800(4)
SRR Radio Timishoara(5)	uk7	1800-1900(5)
	bg7	1900-2000(5)
	rom7	2000-2100
	ro7	2100-2400

SRR Radio Cluj/Kolozsvári Rádió/Radio Bukarest/Bukaresti Rádió

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
909	xx		0550-2200	CJ Cluj-Napoca/Jucu	200		Harris/DX-200	46.867139,23.807611
1593	xx		0550-2200	BH Oradea/Rontău	15		Harris/DX-15	46.999403,22.005028
1593	xx		0550-2200	SB Sibiu	10		Harris/DX-10	45.793272,24.138119

regional program	lan	Mon = 1	ROU time
	ro	123456.	0550-0800
	ro7	0550-1000
	hu	123456.	0800-1000(1)
	hu7	1000-1020(3)
SRR Kolozsvári Rádió(1)	ro	123456.	1000-1400
SRR Radio Bukarest(2)	de7	1020-1030(2)
SRR Bukaresti Rádió(3)	ro7	1030-1400
	de	123456.	1400-1500(2)
	hu7	1400-1800(1)
	hu	123456.	1500-1600(3)
	hu	123456.	1600-1800(1)
	ro		1800-2200

SRR Radio Cluj/Kolozsvári Rádió/Radio Sighet

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
1404	xx		0550-2200	MM Sighetu Marmăției/Vadu Izei	50		Harris/3DX-50	47.877289,23.942892

regional program	lan	Mon = 1	ROU time
	ro	12345..	0550-0600
	ro6.	0550-0800
	ro7	0550-1400
	ro	12345..	0600-0800(2)
	hu	123456.	0800-1000(1)
	ro	12345..	1000-1100
SRR Kolozsvári Rádió(1)	ro6.	1000-1500
SRR Radio Sighet(2)	ro	12345..	1100-1500(2)
	hu7	1400-1800(1)
	ro	12345..	1500-1520(2)
	hu6.	1500-1800(1)
	uk	12345..	1520-1540(2)
	hu	12345..	1540-1600(2)
	hu	12345..	1600-1800(1)
	ro		1800-2200

SRR Radio Târgu Mureş/Marosvásárhelyi Rádió/Radio Neumarkt/Radio Bukarest/Bukaresti Rádió

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
1197	xx	123456.	0545-2200	BV Braşov/Bod Colonie	15		Harris/DX-15	45.755261,25.607367
		7 0545-2000					
1593	xx	123456.	0545-2200	HR Miercurea Ciuc	15		Harris/DX-15	46.367278,25.814500
		7 0545-2000					

regional program	lan	Mon = 1	ROU time
	ro6.	0545-0800
	ro7	0545-1000
	ro	12345..	0545-1100
	hu6.	0800-1100(1)
	hu7	1000-1020(4)
	de7	1020-1030(3)
SRR Marosvásárhelyi Rádió(1)	hu7	1030-1800(1)
SRR Radio Neumarkt(2)	hu	12345..	1100-1400(1)
SRR Radio Bukarest(3)	ro6.	1100-1400
SRR Bukaresti Rádió(4)	de	123456.	1400-1500(3)
	hu	123456.	1500-1600(4)
	hu	123456.	1600-1800(1)
	ro7	1800-2000
	ro	123456.	1800-2100
	de	123456.	2100-2200(2)

SRR Radio Târgu Mureş Minorităţi/Marosvásárhelyi Rádió/Radio Neumarkt

kHz	lan	Mon = 1	ROU time	transmitter location	kW	dir	transmitter	coordinates (N,E)
1323	xx	123456.	0545-2200	MS Târgu Mureş/Ernei	15		Harris/DX-15	46.593231,24.633617
		7 0545-2000					

regional program	lan	Mon = 1	ROU time
	hu67	0545-0700(1)
	hu	12345..	0545-2100(1)
SRR Marosvásárhelyi Rádió(1)	rom67	0700-0800
SRR Radio Neumarkt(2)	hu7	0800-2000(1)
	hu6.	0800-2100(1)
	de	123456.	2100-2200(2)

Radio Vocea Speranței

kHz	lan	Mon = 1	ROU	time	transmitter	location	kW	dir	transmitter	coordinates (N,E)
1485	ro				BT	Botoșani	1	?		?
1485	ro				SB	Mediaș	1	?		?
1485	ro				BH	Oradea	1	?		?
1584	ro				IS	Iași	1	?		?
1584	ro				MM	Sighetu Marmăției	1	?		?
1584	ro				GL	Tecuci	1	?		?
1584	ro				SV	Vatra Dornei	1	?		?
1602	ro				NT	Piatra Neamț	1	?		?

ALT FM

kHz	lan	Mon = 1	ROU	time	transmitter	location	kW	dir	transmitter	coordinates (N,E)
1584	ro				TM	Timișoara	1		Nautel/3kW	?
1602	ro				AR	Arad	1	?		46.213806,21.375167

licensed 23.Nov.2017: [ALT FM]

kHz	lan	Mon = 1	ROU	time	transmitter	location	kW	dir	transmitter	coordinates (N,E)
1575	ro			planned!	CS	Reșița	1	?		?
1602	ro			planned!	HD	Deva	1	?		?

reserve: [SRR Radio România Actualități]

kHz	lan	Mon = 1	ROU	time	transmitter	location	kW	dir	transmitter	coordinates (N,E)
1458	ro			reserve!	CT	Constanța/Agigea	50	?		44.089722,28.603333